Deep Learning

- Convolutional Neural Network -

2019 - 2020

Ando Ki, Ph.D. adki@future-ds.com


Table of contents

- CNN
- CNN: convolution
- CNN: pooling
- CNN abstraction
- CNN examples

(2)

CNN: Convolutional Neural Network


- CNN is a neural network that uses convolution in place of general matrix multiplication in at least one of their layers.
- General form of CNN (Convolutional Neural Network) for image classification
 - ► Feature extraction
 - Convolution
 - Pooling (sub-sampling)
 - Classification
 - Regression



(3)


CNN: convolution

Convolution is a matrix multiplication



It can be seen as a feature extractor






https://adeshpande3.github.io/adeshpande3.github.io/A-Begi nner's-Guide-To-Understanding-Convolutional-Neural-Netwo rks/

(4)

CNN: convolution padding No padding convolution Valid padding \otimes convolution Zero padding Same padding due to input and out have the same dimensions.




How to choose filters

- With CNN/ConvNet the goal is to learn the filters; you don't actually design these filters (or kernels). They will be learned during training as long as the training converges.
- Initializing the these filter parameters with good defaults before starting the training is key to convergence especially in very deep networks.
- Convolution filters can be initialized in one of the following ways.
 - ▶ 1. Randomly assigning weights for the different filters.
 - 2. Handcrafting the weights of the different filters to detect specific features during convolution.
 - ▶ 3. Learning filter weights using unsupervised training schemes.


(7)


Deep learning: Learning Hierarchical Representations




Feature visualization of convolutional net trained on ImageNet from [Zeiler & Fergus 2013]

4













Table of contents

- Convolution by matrix multiplication
- Convolution and deconvolution
- Standard convolution
- Separable convolution: spatially separable
- Separable convolution: depthwise separable

Convolution by matrix multiplication








Convolution and deconvolution


- Standard convolution (discrete convolution)
 - to extract feature map

- Standard deconvolution
 - known as transposed convolution
 - ▶ to reconstruct original image
 - ▶ a reverse operation of convolution



Dilated convolution (atrous convolutions)

- Similar with deconvolution used in real-time segmentation
- smaller kernel for wider view
- not reverse operation (i.e, not reconstruction of original image)




Separable convolution: spatially separable

- standard convolution
 - multiplicationsK*K * W*W
- kernel divided

$$\begin{bmatrix} -1 & 0 & 1 \\ -2 & 0 & 2 \\ -1 & 0 & 1 \end{bmatrix} = \begin{bmatrix} 1 \\ 2 \\ 1 \end{bmatrix} \times \begin{bmatrix} -1 & 0 & 1 \end{bmatrix}$$

- spatially separable convolution
 - multiplications
 - - 2/K ratio comparing to standard convolution




$$\begin{bmatrix} 3 & 6 & 9 \\ 4 & 8 & 12 \\ 5 & 10 & 15 \end{bmatrix} = \begin{bmatrix} 3 \\ 4 \\ 5 \end{bmatrix} \times \begin{bmatrix} 1 & 2 & 3 \end{bmatrix}$$


Although spatially separable convolutions save cost, it is rarely used in deep learning. One of the main reason is that <u>not all kernels can be divided into two, smaller kernels</u>.

Separable convolution: depthwise separable

Standard convolution and depthwise separable (no channel-wise conv)





■ MobileNet case



Separable convolution: depthwise separable

- Standard convolution
 - uses kernels of a number of output channels
- Depth wise separable
 - Depthwise convolution: filtering stageuses kernels of a number of input channels
 - ► Pointwise convolution: combining state
 - uses kernels of a number of output channels





㈜퓨쳐디자인시스템 34051 대전광역시 유성구 문지로 193, KAIST 문지캠퍼스, F723호 (042) 864-0211~0212 / contact@future-ds.com / www.future-ds.com

Future Design Systems, Inc. Faculty Wing F723, KAIST Munji Campus, 193 Munji-ro, Yuseong-gu, Daejeon 34051, Korea +82-042-864-0211~0212 / contact@future-ds.com / www.future-ds.com



